






SPARE PARTS EXPLODED VIEW
GAS-WALL BOILER ATM. BURNER
Model
T2 23 MI

R8217717-01 - 11/01/2017

T2 23 MI

Gas-wall boiler atm. burner




1	535423	T2 23 MI MET	02-2000	05-2007
2	535424	T2 23 MI GPL	02-2000	05-2001
Col	Reference	Model type	Begin	End



☞	Description	Manf. Pt. N	Type	T2-23 MI NG T2-23 MI LPG																From	to	
				1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
0002	EXPANSION VESSEL 6L	998616		●	●																	
0003	BUSH (EXPANSION VESSEL)	998776		●	●																	
0004	LOCK NUT 3/8"	998581		●	●																	
0005	GASKET 3/8"	573521		●	●																	
0006	PIPE (EXPANSION VESSEL)	999105		●	●																11/01	
	PIPE (EXPANSION VESSEL)	999525		●	●															12/01		
0007	CABLE HOLDER	998580		●	●																	
0009	SPRING (FASTENING)	570717		●	●																	
0010	PIVOT	995492		●	●																	
0011	BY-PASS PIPE	998589		●	●																	
0012	O-RING	998077		●	●																	
0013	SPRING (BY-PASS PIPE)	998064		●	●																	
0015	FLOW GROUP	996049		●	●															12/01		
	FLOW GROUP	998612		●	●																11/01	
0016	GASKET 1/2"	573528		●	●																	
0017	SAFETY VALVE	998447		●	●																	
0018	GASKET 1/4	569390		●	●																	
0019	LOW PRESSURE SWITCH	995903		●	●																	
0020	UNION (HOT WATER OUTLET)	998611		●	●																	
0021	TAP FITTING	996050		●	●																	
0022	FILLING COCK KNOB	571559		●	●																	
0023	RETURN GROUP	996048		●	●																	
0024	O-RING	998424		●	●																	
0025	PUMP BRACKET	999162		●	●																	
0026	KIT FOR REAR PUMP ATTACHMENT	996614		●	●																	
0027	LOCK WASHER	999100		●	●																	
0029	U-CLIP	997153		●	●																	
0030	CABLE (P.C.B. - PUMP)	999968		●	●																	
0031	LED (L=14.2)	998577		●	●																	
0032	SPINDLE (KNOB)	999592		●	●																	
0033	CONTROL KNOB	999668		●	●																	
0034	SPRING (PUSH BUTTON)	999595		●	●																	
0035	CONTROL PANEL BUTTON	999977		●	●																	
0037	CONTROL PANEL	995460		●	●																	
0038	PRINTED CIRCUIT BOARD (BT2M-HS)	65100248		●	●																	
0039	NYLON BUSH (10MM)	569711		●	●																	
0040	PRESSURE GAUGE	65100695		●	●																	
0042	CABLE HOLDER COVER	998953		●	●																	
0043	U-CLIP	571548		●	●																	
0044	CABLE (POWER SUPPLY)	65101073		●	●																	
0045	LOW VOLTAGE WIRING	998635		●	●															12/01		
	LOW VOLTAGE WIRING	999387		●	●																11/01	
0048	SPRING (FLUE CONTROL PROBE)	573349		●	●																	
0049	CABLE (FLUE CONTROL PROBE)	995309		●	●																	
0051	PANEL (INSULATION - REAR)	996126		●	●																	
0052	PANEL (L.H. SIDE)	995893		●	●																	
0053	TEMPERATURE PROBE	998458		●	●																	
0054	PANEL (INSULATION - SIDE)	998639		●	●																	
0055	EXCHANGER (TWIN PASS)	998619		●	●																	
0056	WIRING (PROBE)	65103142		●	●																	
0057	PROTECTION SCREEN	999411		●	●																	
0058	PROTECTION SCREEN	999435		●	●																	
0059	BURNER	996158		●																		
	BURNER	998669			●																	
0061	FLOW GAUGE (BITRON - 1/2 M-M)	65100296		●	●																	
0062	EXTENSION (WITH 15 OHM RESISTANCE)	996426		●	●																	
0063	GASKET (SPARK GENERATOR)	574279		●	●																	
0064	SPARK GENERATOR (KIT)	65100514		●	●																	
0065	GAS VALVE	997089		●	●																	
0066	GASKET 3/4"	573520		●	●																	
0067	GAS PIPE	65100432		●	●																	
0068	BURNER JET (L.P.G. 0.77)	998434			●																	
	BURNER JET (NG 1.30)	998433		●																		
0069	BURNER JET WASHER	572138		●	●																	
0072	BLIND GROMMET	569720		●	●																	
0073	CONNECTOR BLOCK	571787		●	●																	
0074	COVER	997745		●	●																	
0075	O-RING	998517		●	●																	
0076	FRONT PANEL	65100555		●	●																	
0077	IGNITION ELECTRODE (R.H.)	65100251		●	●																	

T2 23 MI

Gas-wall boiler atm. burner



LIST OF THE ABBREVIATIONS

HW	: Hot water.
CW	: Cold water.
C	: Ceramic resistance (normal heating).
Ca	: Ceramic resistance (accelerated heating)
TP	: Immersion heater.
1F	: With fittings.
2F	: Without fittings.
3F	: With fittings and another outlet connection.
AMI	: With mixing valve.
SMI	: Without mixing valve.
PUISS	: Power of th appliance.
PN	: Appliance with normal pression.
LP	: Appliance with low pression.
PV	: Appliance with variable power.
PF	: Appliance with fixed power.

IDENTIFICATION PLATE

SERIAL NUMBER

10 Characters :	04 05 125 011	
		Sequential number
		Manufacturing day
		Year of manufacture
11 Characters :	1 95 065004 - 31	
Month of manufacture : from 1 to 9 → Jan. to Sep., O → Oct., N → Nov., D → Dec.		Technical number of the appliance
		Sequential number
		Year of manufacture
19 Characters :	08 05 0013199 900640031	
Year of manufacture		Product reference
Month of manufacture		Sequential number
20 Characters :	3675007 XX 2 07 070 00315	
Product reference		Sequential number
Millenium of manufacture		Manufacturing day
		Year of manufacture
21 Characters :	3675007 XX 07 070 0000315	
Product reference		Sequential number
Year of manufacture		Manufacturing day